Connecting –S and –V/ +V and +S could minimize the damage possibility in using the PV function of RSP-2400/ RSP-3000.

